

SNK-P0035AP4 heatsink installation instruction




Evan Chen
12/ 09/ 2008

Table of Contents

- Installation on X7 UP motherboard (LGA 775).....3
- Installation on X8 UP motherboard (LGA 1366).....5
- How to change the screw position.....7

Installation on X7 UP motherboard (LGA775)



- 1. Peel off the bracket label.**
- 2. Place the bracket (BKT-0008L) on the back of the motherboard.**

Installation on X7 UP motherboard (LGA775)



- 3. Insert four screws to the inner holes.**
- 4. Screw in the heatsink on the motherboard, and make sure the fan is placed at the right position. Blue arrows indicate the air flow direction.**

Installation on X8 UP motherboard (LGA1366)



- 1. Peel off the bracket label.**
- 2. Place the bracket (BKT-0023L) on the back of the motherboard.**

Installation on X8 UP motherboard (LGA1366)



- 3. Insert four screws to the outer holes.**
- 4. Screw in the heatsink on the motherboard, and make sure the fan is placed at the right position. Blue arrows indicate the air flow direction.**

How to change screw position

- The following instruction shows how to change the screw position, if you place the screws on the wrong holes

How to change the screw position



- 1. Squeeze the two edges of the screw holder and push it down till the screw got out**
- 2. Insert the screw into the desired hole**